



TECHNICAL INFORMATION SHEET

Product Name **AIR-CON & INTERIOR SANITISER (NEW CAR & LEMON SCENTS)**

PART NO. RAIRNEW150 & RAIRLEM150

RevEng Air-Con & Interior Sanitiser is a concentrated non-toxic solution in an aerosol form, that is designed to remove the odours, bacterial and fungal growth caused by mould, mildew and bacteria typically found in the vehicle's Heating, Ventilation and Air Conditioning system (HVAC). It kills bacterial and fungal growth at their source. Its microbial action kills the bacteria and mould that builds up on the evaporator. The formula carries a mild scent that will help return that preferred smell to the vehicle. It is designed as an extremely easy to use, hands free product that will produce excellent de-odorising results, especially as a maintenance type product.

RevEng Air-Con & Interior Sanitiser provides the following benefits:

Eliminates bacterial and fungal growth, and associated odour. Freshens and removes odours from vehicle interior surfaces. Aerosol package that has locking nozzle for easy automatic dispensing. Pleasant, mild smell. De-odorising aerosol fog circulates through the entire heating, ventilation and air conditioning system. Leaves the entire interior vehicle environment fresher and cleaner smelling. Requires no tools or special applicators

DIRECTIONS OF USE

Move the passenger seat as far back as possible. Shake well and place the aerosol can in the passenger footwell directly in front of the passenger seat (Do not place the aerosol can under the dashboard or adjacent to the recirculation fan. If there is insufficient room in the passenger footwell such as in small vehicles, place the aerosol can on a flat board on the passenger seat). Face the locking nozzle to the rear of the vehicle. Start engine and leave running. Turn A/C on and set to mid temperature. Set fan to mid speed. Set to Recirculate. Ensure all doors and windows will be closed during the procedure, do not remain in car. To activate can, lock down nozzle. spray action lasts approximately 3. Minutes. Once can is empty, allow to circulate for another 2 minutes. Turn off engine and open doors/windows, then ventilate for a further 5 minutes prior to vehicle entry.

Other methods of deodorising are to spray directly into outside air vents using an extension nozzle, and or short spray directly onto a new cabin filter before installation.



TECHNICAL INFORMATION SHEET



Scan me