



TECHNICAL INFORMATION SHEET

Product Name **HEADLIGHT RESTORER KIT (PART 1 & 2)**

PART NO. HLRKIT OR HLRK3

The Headlight Restorer Kits provide a quick, easy to use 2-part cleaning method. They will convert even the most faded, yellow and hazy lenses back to like new again without the need to sand, scrub, buff or tape up the lens.

RevEng Headlight Restorer Kits provides the following benefits:

Improves night time visibility, improves the overall look of the vehicle. Keeps the vehicle roadworthy where required. Is long lasting.

DIRECTIONS OF USE

It is recommended to apply away from direct heat of sunlight.

Ensure lens is not warm to touch or has a rough surface, if warm, cool them with cold water and then dry. If surface is rough it is recommended to use a light grit 1500 to 2000 sandpaper first.

Use a glass cleaner to remove any dust or grime and then dry surface.

Wearing gloves, remove the wet towel from **yellow** pack no. 1 (DO NOT UNFOLD TOWEL)

Wipe over 1 lens only, in a side-to-side motion until yellow stain appears on towel, wipe off solution from lens at the same time with a clean cloth, not allowing it to dry back onto the lens. Turn over towel and repeat on the **SAME** lens. Once complete, repeat the process on the other headlight lens using the second yellow pack part no.1 towel. Once complete allow 2 minutes for the headlight to dry, it should dry hazy (this is normal)

Next step is to use the **orange** pack no.2 on both lenses, using one side of the towel and in a side-to-side motion, wipe over the lens 2 times or until lens is clear. Turn over the towel and repeat on the other lens. After application do not touch lens for at least 1 hour, allow 48 hours to cure. For best results park vehicle into direct heat or sunlight to speed up drying process. IT IS IMPORTANT TO AVOID ANY MOISTURE, CONDENSATION OR WATER IN THE 48 HOUR CURE TIME. To ensure process is long lasting, avoid harsh car washing and high-pressure hosing.



Scan me



TECHNICAL INFORMATION SHEET

